

Comes to life with realistic
flickering flame effect!

FLAMING ROTTED SKULL™

OPERATING INSTRUCTIONS

KEEP ALL PLASTIC AND WIRE PARTS
AWAY FROM CHILDREN

1. Using a small Philips/crosshead screwdriver, remove screw on bottom of FLAMING ROTTED SKULL™ to insert 3 brand new "AA" alkaline batteries into the battery compartment. Replace cover and screw.
2. Place switch on bottom of FLAMING ROTTED SKULL™ to the "ON" position to activate item.
NOTE: Keep switch in the "OFF" position when not in use.

SURFACE WASHABLE ONLY.

All new materials: plastic.

Item #60064. FLAMING ROTTED SKULL™
is a trademark of Tekky.

Copyright © 2021 Tekky. All Rights Reserved.

Manufactured for:


Tekky, Orland Park, IL 60467 USA
MADE IN CHINA

TekkyDesign.com

3AA BATTERIES REQUIRED (not included)

BATTERY INSTRUCTIONS AND CAUTIONS

- Battery installation and removal should be performed by an adult.
- Batteries are harmful if swallowed, so keep away from young children.
- Remove batteries when not in use.
- Use only batteries recommended in the instructions.
- Do not mix new and used batteries.
- Do not mix alkaline, carbon-zinc, nickel-cadmium, rechargeable or different types of batteries.
- Be mindful to insert batteries with the correct polarity (+/-) as indicated.
- Remove all exhausted batteries.
- Rechargeable batteries are only to be charged under adult supervision.
- Rechargeable batteries are to be removed from the item before being charged.
- Non-rechargeable batteries are not to be recharged.
- The supply terminals are not to be short-circuited.
- Always dispose of exhausted batteries properly.
- Do NOT dispose of batteries in fire, they may leak or explode.



WARNING! CHOKING HAZARD—Small Parts.

This item is not a toy. For decoration only.

This product is intended for use by persons 15 years of age and older.

Not intended for use by children 14 years of age and younger.