

HALLOWEEN PEEK-A- BOO POLLY™

TRY
ME

⚠ WARNING! CHOKING HAZARD - small parts.

This item is not a toy. For decoration only.

This product is intended for use by persons 15 years of age and older.
Not intended for use by children 14 years of age and younger.

OPERATING INSTRUCTIONS

KEEP ALL PLASTIC AND WIRE PARTS AWAY FROM CHILDREN

1. Carefully remove and discard pull tab from the battery compartment on back of PEEK-A-BOO POLLY™. Retailer may have already removed this pull tab to allow for TRY-ME demo.
2. Replace demo batteries with 3 brand new AA alkaline batteries into the battery compartment located on back of doll under fabric.
3. Place switch on module to the DEMO position.
4. Push the TRY-ME button on doll's arm to activate scary sequence.
5. Or place switch on module to the ON position to operate in sound and motion activation mode. Make a loud sound (clap) or wave hand in front of item to activate the scary sequence.


NOTE: After removing pull tab, the function switch must be placed in the DEMO position to operate with TRY-ME button. Place switch to ON to operate item in sound and motion activation mode.

6. Keep switch in the OFF position when not in use.

SURFACE WASHABLE ONLY. All new materials: plastic, fabric.

Item #60366. PEEK-A-BOO POLLY™ is a trademark of Tekky.
Copyright © 2022 Tekky. All rights reserved. MADE IN CHINA.

TekkyDesign.com



REQUIRES
3 AA BATTERIES
(included for demo
purposes only)

BATTERY INSTRUCTIONS AND CAUTIONS

- Battery installation and removal should be performed by an adult.
- Remove batteries when not in use.
- Use only batteries recommended in the instructions.
- Do not mix new and used batteries.
- Do not mix alkaline, carbon-zinc, nickel-cadmium, rechargeable or different types of batteries.
- Be mindful to insert batteries with the correct polarity (+/-) as indicated.
- Remove all exhausted batteries.
- Rechargeable batteries are only to be charged under adult supervision.
- Rechargeable batteries are to be removed from the item before being charged.
- Non-rechargeable batteries are not to be recharged.
- The supply terminals are not to be short-circuited.
- Always dispose of exhausted batteries properly.
- Do NOT dispose of batteries in fire, they may leak or explode.

34 in. (86.36 cm)