

**SOUND AND MOTION ACTIVATED
HALLOWEEN PROP**

AGES
15+



**HANGING
SKELETON
GREETER™**

**TELLS JOKES!
LED LIGHTS AND
ANIMATION!**

3AA

Batteries
included

(for demo purposes only)

**HE'S THE WORLD'S FIRST
"HANG-UP" COMIC!
HANGING SKELETON GREETER™
WILL TICKLE YOUR FUNNY BONE!**

OPERATING INSTRUCTIONS

KEEP ALL PLASTIC AND WIRE PARTS AWAY
FROM CHILDREN

1. Carefully remove and discard the "Try Me" wire and packaging.
2. Insert 3 brand new "AA" alkaline batteries into the battery compartment located on back of the SKELETON'S head.
3. Place the switch to the "ON" position.
4. Wave your hand in front of HANGING SKELETON GREETER™ or make a loud sound (clap) near the item to activate the scary sequence!


NOTE: Keep the switch in the "OFF" position when not in use.

INDOOR/SHELTERED
OUTDOOR USE.
DISPLAY ON LEVEL
SURFACE. SURFACE
WASHABLE ONLY.
All new materials:
plastic, fabric.

TekkyDesign.com

**BATTERY INSTRUCTIONS
AND CAUTIONS**

- Battery installation and removal should be performed by an adult.
- Remove batteries when not in use.
- Use only batteries recommended in the instructions.
- Do not mix new and used batteries.
- Do not mix alkaline, carbon-zinc, nickel-cadmium, rechargeable or different types of batteries.
- Be mindful to insert batteries with the correct polarity (+/-) as indicated.
- Remove all exhausted batteries.
- Rechargeable batteries are only to be charged under adult supervision.
- Rechargeable batteries are to be removed from the item before being charged.
- Non-rechargeable batteries are not to be recharged.
- The supply terminals are not to be short-circuited.
- Always dispose of exhausted batteries properly.
- Do NOT dispose of batteries in fire, they may leak or explode.



TEKKY

**HANGING
SKELETON
GREETER™**

Item #59043. **HANGING SKELETON™** is a trademark of Tekky.
Copyright © 2020 Tekky. All Rights Reserved.

TRACKING CODE



Manufactured for and distributed by:
Tekky, Orland Park, IL 60467 USA
MADE IN CHINA

⚠ WARNING! CHOKING HAZARD—Small Parts.

This item is not a toy. For decoration only.

This product is intended for use by persons 15 years of age and older.
Not intended for use by children 14 years of age and younger.