



**MOTION  
ACTIVATED!**  
¡MOVIMIENTO  
ACTIVADO!

# HAUNTED HANNAH™

She'll haunt YOU!  
Glowing eyes  
& creepy talk!

¡Ella te ATORMENTARÁ!  
¡Ojos brillantes y palabras  
escalofriantes!

**3AAA**

Batteries Included  
(for demo purposes only)

3 pilas "AAA" incluidas  
(solo con fines de demostración)

She'll haunt your nightmares  
with her glowing eyes  
and creepy talk!

## OPERATING INSTRUCTIONS

KEEP ALL PLASTIC AND WIRE PARTS  
AWAY FROM CHILDREN

1. Carefully remove and discard the "Try Me" wire and packaging.
2. Insert 3 brand new "AAA" alkaline batteries into the battery compartment located on the bottom of Doll's base.
3. Place switch on the module inside the back of Doll's dress to the "ON" position.
4. Wave hand in front of Doll to activate scary sequence.

**NOTE:** Keep the switch in the "OFF" position when not in use.

**SURFACE WASHABLE ONLY.**  
All new materials:  
polyester fibres, plastic, wire


Item #58633  
HAUNTED HANNAH™  
is a trademark of Tekky.  
Copyright © 2018 Tekky.  
All Rights Reserved.  
MADE IN CHINA

Manufactured for and  
distributed by: Tekky,  
Orland Park, IL 60467 USA

[TekkyDesign.com](http://TekkyDesign.com)

## BATTERY INSTRUCTIONS AND CAUTIONS

- Battery installation and removal should be performed by an adult.
- Remove batteries when not in use.
- Use only batteries recommended in the instructions.
- Do not mix new and used batteries.
- Do not mix alkaline, carbon-zinc, nickel-cadmium, rechargeable or different types of batteries.
- Be mindful to insert batteries with the correct polarity (+/-) as indicated.
- Remove all exhausted batteries.
- Rechargeable batteries are only to be charged under adult supervision.
- Rechargeable batteries are to be removed from the item before being charged.
- Non-rechargeable batteries are not to be recharged.
- The supply terminals are not to be short-circuited.
- Always dispose of exhausted batteries properly.
- Do NOT dispose of batteries in fire, they may leak or explode.



**WARNING! CHOKING HAZARD**—Small Parts.

This item is not a toy. For decoration only.

This product is intended for use by persons 15 years of age and older.

Not intended for use by children 14 years of age and younger.