

HAUNTED HEDGE™

Easy Set-Up Instructions

1. Remove parts from the box and detach "Try Me" Cable.
2. Replace the batteries with brand new fresh alkaline batteries.
(this item is shipped with light-duty batteries for demo purposes only).
3. Insert round shakey device into center of plant where it will not be seen.
4. Attach wire ties around and through plant branches and pull taut. (Make sure to weave wire around and through as many branches as possible, this will make more of the plant move.)
5. Repeat for other wires, keeping wires **VERY TAUT**.
6. Turn switch to 'ON' to activate item. Haunted Hedge™ is sound activated by any loud sound.

OPERATING YOUR HAUNTED HEDGE OUTDOORS

For best overall performance, we recommend you bring your haunted hedge™ indoors during adverse weather conditions (extreme cold, strong winds and/or rain). The haunted hedge™ is intended for use outdoors in sheltered areas and in temperatures above freezing (32° F). Tekky Toys recommends using heavy-duty, alkaline batteries for best operating performance.

Warning! Strangulation Risk! Keep cables and wires away from children.
This item is not a toy. For decoration only. Small parts, choking hazard.
This product is intended for use by persons 14 years of age and older.
NOT intended for use by children 13 years of age and younger.

Haunted Hedge™ is a trademark of Tekky Toys.
Copyright 2007-2009 Tekky Toys, All Rights Reserved.
Requires 4 'AA' Batteries, included for demo purposes only.
MADE IN CHINA



Tekky Toys Item #56010
Haunted Hedge™


Manufactured for and distributed by
Tekky Toys, Orland Park, IL, USA



DO NOT RETURN THIS ITEM TO THE STORE!

If you are experiencing technical difficulties, please go to www.tekkytoys.com for assistance.

Battery compartment is located on the bottom of the device.



NOTICE REGARDING BATTERIES:

This product may be shipped with batteries for in-store demonstration purposes ONLY. Tekky Toys does not guarantee the life of any batteries used for demonstration. Tekky Toys recommends the consumer REPLACE any demonstration batteries present with fresh cells to ensure proper operation and enjoyment.

BATTERY INSTRUCTIONS AND CAUTIONS:

- Use only the batteries recommended.
 - Remove batteries when not in use.
 - Do NOT use rechargeable batteries.
 - Be sure to insert the batteries with the correct polarity +/-.
 - Never mix different types of batteries: old and new, carbon-zinc, Alkaline, Nickel-Cadmium batteries.
- Always dispose of exhausted batteries properly.

Be sure to insert the batteries correctly as shown above. Do NOT dispose of batteries in fire, batteries may leak or explode.

ADULT SUPERVISION IS RECOMMENDED WHEN CHANGING BATTERIES.