

HIGH VOLTAGE™

SET UP:

1. Insert 3 brand new alkaline batteries. *(not included)*
2. Hang High Voltage in desired location. *(mounting hardware not included)*
3. Turn the switch to the 'ON' position.
4. Push skull lever the right, gently pushing down to trigger the activation button behind switch.

MIT Multiple Trigger Set-up Instructions

Note:

Use in conjunction with any item that transmits MIT signal.

1. Plug MIT cable into MIT jacks on both items.
2. Turn switch on Death Row to footpad/MIT to activate.
3. Activate transmitting item to force activation of Death Row™ or John Doe™.

TROUBLESHOOTING

If High Voltage's door will not open, follow the steps below to reset the opening mechanism:

- Turn item OFF
- Force door open fully
- Turn item ON
- Activate the item

WARNING!

STAND AT A SAFE DISTANCE WHEN OPERATING

This item is not a toy. For indoor and decoration use only. Small parts, choking hazard.

This product is intended for use by persons 15 years of age and up.

This product is NOT intended for use by children 14 years of age and younger.

FOR INDOOR USE ONLY.

NO WEIGHT SHOULD BE PLACED ON THIS ITEM.

