

LUNGING MONUMENT™

INSTALLATION AND OPERATING INSTRUCTIONS


KEEP ALL PLASTIC AND WIRE PARTS AWAY FROM CHILDREN

WARNING: DO NOT TURN ON THE PROP UNTIL FULLY ASSEMBLED. STAY CLEAR OF THE PROP WHILE OPERATING.
ESTIMATED ASSEMBLY TIME SEVEN MINUTES.


PARTS:

1. HEAD & BODY FRAME
2. LEFT WING
3. RIGHT WING
4. LUNGING MODULE
5. BASE BACK & CONTROL BOX
6. BASE FRONT
7. LOWER BACK POLE
8. LOWER FRONT POLE
9. UPPER BACK POLE
10. UPPER FRONT POLE
11. ADAPTER
12. CLEVIS AND COTTER PIN

PARTS




ASSEMBLY




1. Snap lock BASE BACK & CONTROL BOX into the BASE FRONT.

MATCH A to A and MATCH B to B




2. Snap lock LOWER FRONT POLE to the BASE BACK & CONTROL BOX.

MATCH C to C




3. Snap lock LOWER BACK POLE to BASE BACK & CONTROL BOX.

MATCH D to D




4. Connect the LUNGING MODULE to the BASE BACK & CONTROL BOX with the CLEVIS AND COTTER PIN.

MATCH E to E




5. Push in the circular locking pin located on the LOWER BACK POLE. Snap lock the F end of the LUNGING MODULE to LOWER BACK POLE.

MATCH F to F




6. Snap lock the G end of the UPPER BACK POLE to the LOWER BACK POLE.

MATCH G to G




7. Snap lock the H end of the UPPER FRONT POLE to the LOWER FRONT POLE.

MATCH H to H



8. Move HEAD & BODY FRAME's fabric out of the way to access the base of the head. Snap lock the base of the HEAD & BODY FRAME onto the UPPER FRONT POLE.

MATCH I to I



9. Snap lock HEAD & BODY FRAME's pole, labeled J, to the UPPER BACK POLE.

MATCH J to J



10. Locate the two wing posts on the HEAD & BODY FRAME.




11. Snap lock the RIGHT WING to the wing post labeled K.

MATCH K to K



12. Hook and loop fasten the RIGHT WINGS's fabric to the back right shoulder of the HEAD & BODY FRAME.




13. Snap lock the LEFT WING to the wing post labeled L.

MATCH L to L




14. Hook and loop fasten the LEFT WING's fabric to the back left shoulder of the HEAD & BODY FRAME.



15. Connect the wire assemblies located on the BACK BASE & CONTROL BOX to the LUNGING MODULE. CONNECT M to M and CONNECT N to N



16. Adjust the HEAD & BODY's fabric around the BASE and secure the fabric with the hook and loop fasteners to the BASE.




17. Insert 4 fresh alkaline batteries (recommended) or insert 6V 2A ADAPTER (Included). Turn the switch to the ON position to operate in Sound or Motion activation mode. Make a loud sound (clap), or move in front of the item to activate. Turn item OFF when not in use.

OPTIONAL EXTERNAL SPEAKER SET UP

EXTERNAL SPEAKER IS NOT INCLUDED. MUST BE PURCHASED SEPARATELY.

Plug speaker cord into the jack labeled **SPEAKER JACK** located on the **CONTROL BOX**.

2. Use volume knob on external speaker to control volume levels.




OPTIONAL EXT. TRIGGER SET UP

EXT. TRIGGER IS NOT INCLUDED. MUST BE PURCHASED SEPARATELY.

1. Insert the cable from EXT. TRIGGER into the jack labeled **EXT. TRIGGER JACK** on the **CONTROL BOX**.
2. Place the switch in the **EXT. TRIGGER** position to enable EXT. TRIGGER activation.
3. Step on the **EXT. TRIGGER** to activate the scary sequence!
Footpads are sold separately and can be purchased at www.tekkyaccessories.com*



Battery Diagram



BATTERY INSTRUCTIONS AND CAUTIONS

Battery installation and removal should be performed by an adult.
Remove batteries when not in use.
Use only batteries recommended in the instructions.
Do not mix new and used batteries.
Do not mix alkaline, carbon-zinc, nickel-cadmium, rechargeable or different types of batteries.
Be mindful to insert batteries with the correct polarity (+/-) as indicated.
Remove all exhausted batteries.
Rechargeable batteries are only to be charged under adult supervision.
Rechargeable batteries are to be removed from the item before being charged.
Non-rechargeable batteries are not to be recharged.
The supply terminals are not to be short-circuited.
Always dispose of exhausted batteries properly.
Do NOT dispose of batteries in fire, they may leak or explode.

Warning! This item is not a toy. For decoration only. Small parts, choking hazard.
This product is intended for use by persons 15 years of age and older.
Not intended for use by children ages 14 years and younger.


WARNING

DO NOT TURN ITEM ON UNTIL YOU HAVE COMPLETELY FINISHED ASSEMBLY.
STAY CLEAR OF ITEM WHILE OPERATING.
DO NOT PLACE ITEM ON UNEVEN GROUND.
DO NOT PLACE WEIGHT ON ITEM WHILE IN OPERATION.




DO NOT RETURN THIS ITEM TO THE STORE!
If experiencing technical difficulties, please go to www.tekkydesign.com for assistance.


STORAGE AND REASSEMBLY




1
Insert and secure the POP UP MODULE to the METAL BASE. (Match E to E) Insert the LARGE CLEVIS PIN through the METAL BASE through the POP UP MODULE. Slide the COTTER PIN through the CLEVIS PIN to secure the POP UP MODULE.




2
**! WARNING !
THE SWITCH MUST
BE IN THE OFF
POSITION THROUGH
ENTIRE PROCESS.**




3
Connect the POP UP MODULE wire TO THE CONTROL BOX.
CONNECT N TO N.



4
With the switch in the off position apply power. Plug in an adapter or insert Batteries.



5
**WAIT FOR THE MODULE
POLE TO FULLY RETRACT
AND STOP.**



6
Disconnect power (Remove a battery or unplug adapter) continue assembly.



TEKKY

visit us at tekkydesign.com

Requires 6V 2A ADAPTER (included)
or 4AA batteries (not included)

ALL NEW MATERIALS:
METAL, FOAM, PLASTIC, POLYESTER
Surface washable only.

LUNGING MONUMENT™
is a trademark of Tekky.

Copyright © 2023 Tekky
All Rights Reserved.
MADE IN CHINA



**SMART PHONE SCAN
SETUP VIDEO**

