

LED FLYING BAT™

Operating Instructions

KEEP ALL PLASTIC AND WIRE PARTS AWAY FROM CHILDREN

1. Carefully remove and discard the “Try Me” wire and packaging.
2. Replace demo batteries with 3 brand new “AA” alkaline batteries into the battery compartment located on back of LED FLYING BAT™.
3. Place switch on the module to the “ON” position to operate item.

NOTE: Keep the switch in the “OFF” position when not in use.

THIS ITEM IS NOT A TOY.
FOR DECORATION PURPOSES ONLY.

Product dimensions:
24.21 in h x 8.66 in w x 1.77 in d

Includes:
1 LED FLYING BAT™ decoration.
All new materials: plastic.
Surface washable only.
Indoor/sheltered outdoor use.

Item #59047. LED FLYING BAT™
is a trademark of Tekky.
Copyright © 2021 Tekky. All Rights Reserved.
MADE IN CHINA
Manufactured for: Tekky, Orland Park, IL 60467 USA

TekkyDesign.com

Battery Instructions & Cautions

- Battery installation and removal should be performed by an adult.
- Batteries are harmful if swallowed, so keep away from young children.
- Remove batteries when not in use.
- Use only batteries recommended in the instructions.
- Do not mix new and used batteries.
- Do not mix alkaline, carbon-zinc, nickel-cadmium, rechargeable or different types of batteries.
- Be mindful to insert batteries with the correct polarity (+/-) as indicated.
- Remove all exhausted batteries.
- Rechargeable batteries are only to be charged under adult supervision.
- Rechargeable batteries are to be removed from the item before being charged.
- Non-rechargeable batteries are not to be recharged.
- The supply terminals are not to be short-circuited.
- Always dispose of exhausted batteries properly.
- Do NOT dispose of batteries in fire, they may leak or explode.

