


PEEK-A-BOO BEAR™

Item # 58322L
& 58322B

OPERATING INSTRUCTIONS:

1. Insert 3 brand new 'AA' alkaline batteries into the battery compartment located on the bottom of the bear.
2. Place the switch on the module to the "ON" position.
3. Squeeze the TRY-ME symbol on foot to activate scary sequence.

NOTE: Keep the switch in the "OFF" position when not in use.



BATTERY INSTRUCTIONS & CAUTIONS:

- Use only the batteries recommended by the manufacturer.
 - Remove batteries when not in use.
 - Do NOT use rechargeable batteries.
 - Be sure to insert the batteries with the correct polarity +/-.
 - Never mix different types of batteries: old and new, carbon-zinc, alkaline, nickel-cadmium.
 - Always dispose of exhausted batteries properly.
 - Do NOT dispose of batteries in fire, they may leak or explode.
- Adult supervision recommended when changing batteries.**

FOR FOOTPADS, ADAPTERS, AND ALL OTHER ACCESSORIES, PLEASE VISIT:
www.tekkyaccessories.com



DO NOT RETURN THIS ITEM TO THE STORE!
If experiencing technical difficulties, please go to www.tekkydesign.com for assistance.



WARNING:

Not a toy. Decorative use only.
This product is intended for use by persons 15 years of age and older.

Surface Washable Only.

ALL NEW MATERIALS : PLASTIC, POLYESTER

Battery Powered: Requires 3 "AA" Batteries (included)

PEEK-A-BOO BEAR is a trademark of Tekky.
Copyright © 2016 Tekky. All Rights Reserved.

MADE IN CHINA



TEKKY

www.tekkydesign.com