
POSSESSED BABY

INSTALLATION AND OPERATING INSTRUCTIONS

KEEP ALL PLASTIC AND WIRE PARTS AWAY FROM CHILDREN





PARTS


- 1. Frame SIDE PANELS (2)
- 2. Frame CONNECTION POLES
- 3. Frame HANDLE
- 4. CART, HOOD and MODULE
- **5. BABY**
- 6. WHEELS (4)
- 7. REMOTE (Located inside the pocket on back of CART, under the handle)


TWO OR MORE PEOPLE ARE RECOMMENDED WHEN ASSEMBLING THIS ITEM


- 1. Push down the metal ring located at the center of the outside WHEEL while inserting the wheel onto the shaft located on the bottom of the SIDE PANEL. Repeat this step for the remaining three wheels. See illustration 1a and 1b.
- **2.** Connect **SIDE PANELS** to one another using **CONNECTION POLES**, matching D to D. Pole is secure when snap lock pin clicks into post on side panel. Repeat step for other connection pole.
- **3.** Place the **CART, HOOD and MODULE** on top of assembled **SIDE PANELS**. Connect the **CART, HOOD and MODULE** to the **SIDE PANELS**, matching C to C. Pole is secure when snap lock pin clicks into post on side panel.
- **4.** Attach **HANDLE** to poles located on the sides of **CART, HOOD and MODULE**, matching B to B. Pole is secure when snap lock pin clicks into post on baby cart.
- **5.** Connect the wire from **HANDLE** to wire from **CART, HOOD and MODULE,** matching A to A.
- **6.** Attach **BABY** to **CART, HOOD and MODULE**. Line up the pole under baby clothing with the groove in module, matching E to E.
- **7.** Attach the wire inside **BABY's** clothes to the jack on the **MODULE** labeled F, matching F to F.
- **8.** Insert 4 AA alkaline batteries (not included) into the battery compartment located near the front inside **CART, HOOD and MODULE** or connect a 6V 2A DC adapter (sold separately) into the jack on the **MODULE**.
 - *NOTE: Possessed Baby requires a great deal of power. If using batteries, you will need to replace the batteries frequently. Use the battery compartment located inside the front of cart, the battery compartment located on top of the module will not be used.
- **9.** Insert 2 AAA batteries (not included) into the battery compartment located on the back of **REMOTE**.



























Possessed Baby uses a three way switch located on top of module:


ON = BUTTONS & REMOTE FOOTPAD = OFF & FOOTPAD SENSOR = MOTION & SOUND

- 1. **ON**: for activation using the **HANDLE** buttons or **REMOTE**. There are 2 buttons on the **HANDLE** and **REMOTE**, labeled 1 and 2, (see illustration A).
 - 1 = Activates the 1st sequence making Baby talk and coo.
 - 2 = Activates 2nd sequence making Baby sit up and scream.
- *NOTE: Holding down button 2 will make the baby stay upright until the button is released, then baby will lie back down.

To activate baby using **REMOTE**, point the remote at the sensor located between the two buttons on **HANDLE**. (see illustration B). There must be a direct line of sight when pointing **REMOTE** at sensor in order to activate the Baby. There can be no objects in between the **REMOTE** and sensor.

- 2. **FOOTPAD**: for activation using a Footpad (sold separately). Pressing the Footpad will trigger an entire shortened sequence. FOOTPAD is also the OFF switch. Leave switch in FOOTPAD (OFF) position when not in use.
- 3. **SENSOR**: for activation using MOTION and SOUND. Make a loud sound (clap) or move in front of the item to activate.
- **10.** Adjust sound with **VOLUME CONTROL KNOB** located on the **MODULE** as needed.






Optional Footpad Setup

Follow steps #1 through 8 on initial installation first.

- 1. Connect the cable from the optional footpad to the jack labeled FOOTPAD located on the MODULE.
- 2. Place the switch on the MODULE into the 'FOOTPAD' position to enable FOOTPAD activation.
- 3. Step on FOOTPAD to activate the scary sequence. (go to instruction #9 to continue setup)

*Footpads are sold separately and can be purchased at **www.tekkytoys.com**



WARNING

DO NOT TURN ITEM ON UNTIL YOU HAVE COMPLETELY FINISHED ASSEMBLY.

STAY CLEAR OF ITEM WHILE OPERATING.

DO NOT PLACE ITEM ON UNEVEN GROUND.

DO NOT PLACE WEIGHT ON ITEM WHILE IN OPERATION



DO NOT RETURN THIS ITEM TO THE STORE! If experiencing technical difficulties, please go to www.tekkytoys.com for assistance.

Tekky Toys Hours of Operation: Monday - Friday 9am to 5pm CST T: 708-478-8424 E: support@tekkytoys.com visit us: tekkytoys.com



Surface Washable Only.
ALL NEW MATERIALS: WOOD, METAL,
PLASTIC, FOAM, POLYESTER,
POLYESTER FIBER

Possessed Baby requires 4'AA' Batteries (not included) or 6V 2A DC adapter (sold separately)
Remote requires 2'AAA' Batteries (not included)
POSSESSED BABY is a trademark of Tekky Toys.
Copyright © 2014 Tekky Toys. All Rights Reserved.

MADE IN CHINA

