

**ANIMATED PROP! SCARY HALLOWEEN LIGHTS AND SOUNDS! POSEABLE ARMS**

# TERROR CLOWN™



## OPERATING INSTRUCTIONS

KEEP ALL PLASTIC AND WIRE PARTS AWAY FROM CHILDREN.


1. Carefully remove and discard the "Try Me" wire and packaging.
2. Insert 3 brand new "AA" alkaline batteries into the battery compartments located on the bottom of Clown's feet.
3. Place the switch on the Clown to the "ON" position.
4. Squeeze Clown's leg to activate scary sequence.
5. Terror Clown™ has bendable arms! Pose him as pictured or as you wish.

**NOTE:** Keep the switch in the "OFF" position when not in use.

## BATTERY INSTRUCTIONS AND CAUTIONS

- Battery installation and removal should be performed by an adult.
- Remove batteries when not in use.
- Use only batteries recommended in the instructions.
- Do not mix new and used batteries.
- Do not mix alkaline, carbon-zinc, nickel-cadmium, rechargeable or different types of batteries.
- Be mindful to insert batteries with the correct polarity (+/-) as indicated.
- Remove all exhausted batteries.
- Rechargeable batteries are only to be charged under adult supervision.
- Rechargeable batteries are to be removed from item before being charged.
- Non-rechargeable batteries are not to be recharged.
- The supply terminals are not to be short-circuited.
- Always dispose of exhausted batteries properly.
- Do NOT dispose of batteries in fire, they may leak or explode.

HIS LEFT HIS RIGHT



## BATTERY OPERATED

**Requires 3 "AA" batteries**

(included for demonstration purposes only)

ALL NEW MATERIALS:

POLYESTER FIBRES, PLASTIC, WIRE

SURFACE WASHABLE ONLY.

Actual item may vary from the photograph.

Item #58548.

TERROR CLOWN™ is a trademark of Tekky.

Copyright © 2018 Tekky. All Rights Reserved.

MADE IN CHINA

Manufactured for and distributed by:

Tekky, Orland Park, IL 60467 USA

**TekkyDesign.com**



**WARNING! CHOKING HAZARD—Small Parts.**

This item is not a toy. For decoration only.

This product is intended for use by persons 15 years of age and older.

Not intended for use by children 14 years of age and younger.