

TERROR CLOWN™

**This terrifying clown
has a sharp wit and a
cutting sense of humor!**

You'll die laughing!

Crazy stabbing motion!

Scary lights and sounds

Sound activated

SURFACE WASHABLE ONLY.

All new materials: polyester, plastic, wire
Actual item may vary from the photographs
and/or illustrations on package.

OPERATING INSTRUCTIONS:

**KEEP ALL PLASTIC AND WIRE PARTS
AWAY FROM CHILDREN**


1. Insert 3 brand new AA alkaline batteries into the battery compartment located on the bottom of clown's feet.
2. Place the switch on the module to the "ON" position.
3. Push "Try Me" button to activate scary sequence.

Note: Keep the switch in the "OFF" position when not in use.

Item #58402 Terror Clown™ is a trademark of Tekky.
Copyright © 2018 Tekky. All Rights Reserved.
MADE IN CHINA

WARNING!
CHOKING HAZARD—Small Parts.
This item is not a toy. For
decoration only. This product is
intended for use by persons 15
years of age and older. Not
intended for use by children 14
years of age and younger.

HIS LEFT



HIS RIGHT



BATTERY INSTRUCTIONS AND CAUTIONS:

- Battery installation and removal should be performed by an adult.
- Remove batteries when not in use.
- Use only batteries recommended in the instructions.
- Do not mix new and used batteries.
- Do not mix alkaline, carbon-zinc, nickel-cadmium, rechargeable or different types of batteries.
- Be mindful to insert batteries with the correct polarity (+/-) as indicated.
- Remove all exhausted batteries.
- Rechargeable batteries are only to be charged under adult supervision.
- Rechargeable batteries are to be removed from the item before being charged.
- Non-rechargeable batteries are not to be recharged.
- The supply terminals are not to be short-circuited.
- Always dispose of exhausted batteries properly.
- Do NOT dispose of batteries in fire, they may leak or explode.