

GLOW IN THE DARK TOMBSTONE

NOTICE:

Do NOT leave the Glow-in-the-Dark Tombstone™ outside during adverse weather conditions (such as rain, sleet or snow).

1. FOR OUTDOOR DISPLAY:

Carefully insert ONE of the LONG spikes (pictured below) into the bottom of the tombstone, on each side. Make sure the insertion is straight and level. To use as an outdoor decoration, carefully insert the opposite sides of the feet into the ground. TAKE CARE to use caution when inserting the other LONG spike into the ground. The spikes are made of plastic and should be inserted into soft ground or they may break.

FOR INDOOR DISPLAY:

Insert the SHORT spike on the plastic feet into the bottom of the tombstone. The long spikes will help the tombstone to stand on the floor.

2. Replace the light-duty demonstration batteries with heavy-duty brand new 3 'AAA' Batteries.

3. Place the switch in the 'ON' position to operate.

Plastic Spikes
are included for
Outdoor or
Indoor Display.



GLOW-IN-THE-DARK-TOMBSTONE™
is a trademark of Tekky Toys.
Copyright © 2008 Tekky Toys.
All Rights Reserved.

FILLING: ALL NEW MATERIALS.
SURFACE WASHABLE ONLY.
Requires 3 'AAA' Batteries
MADE IN CHINA

Item #56210
Glow-in-the-Dark
Tombstone™

Manufactured for and distributed by
Tekky Toys, Orland Park, IL, USA

**Warnings:**

This item is not a toy.
For Decoration only.

Small parts, choking hazard.

This product is intended for use by persons 14 years of age and older.

Not intended for use by children 13 years of age and younger.

visit us:

www.tekkytoys.com